User guide

MAGNAVOX
SMART. VERY SMART.

MDV430 *DIGITAL VIDEO DISC PLAYER*

3139 246 14551

Important notes for users in the U.K.

Mains plug

This apparatus is fitted with an approved 13 Amp plug. To change a fuse in this type of plug proceed as follows:

1 Remove fuse cover and fuse.

2 Fix new fuse which should be a BS1362 5 Amp, A.S.T.A. or BSI approved type.

3 Refit the fuse cover.

If the fitted plug is not suitable for your jack outlets, it should be cut off and an appropriate plug fitted in its place.
If the mains plug contains a fuse, this should have a value of 5 Amp. If a plug without a fuse is used, the fuse at the distribution board should not be greater than 5 Amp.

Note: The severed plug must be disposed to avoid a possible shock hazard should it be inserted into a 13 Amp jack elsewhere.

How to connect a plug

The wires in the mains lead are coloured with the following code: blue = neutral (N), brown = live (L).

- As these colours may not correspond with the colour markings identifying the terminals in your plug, proceed as follows:
  – Connect the blue wire to the terminal marked N or coloured black.
  – Connect the brown wire to the terminal marked L or coloured red.
  – Do not connect either wire to the earth terminal in the plug, marked E (or ⏚) or coloured green (or green and yellow).

  Before replacing the plug cover, make certain that the cord grip is clamped over the sheath of the lead - not simply over the two wires.

Copyright in the U.K.

Recording and playback of material may require consent. See Copyright Act 1956 and The Performer's Protection Acts 1958 to 1972.

CAUTION

Use of controls or adjustments or performance of procedures other than herein may result in hazardous radiation exposure or other unsafe operation.

VAROITUS

Muiden kuin tässä esitettyjen toimintojen säädön tai asetusten muutto saattaa altistaa vaaralliselle säteilylle tai muille vaarallisille toiminnoille.

DK

Advarsel: Usynlig laserstråling ved åbning når sikkerhedsafbrydere er ude af funktion. Undgå utsættelse for stråling.

Bemærk: Netafbryderen er sekundært indkoblet og ofbryder ikke strømmen fra nettet. Den indbyggede netdel er derfor tilsluttet til lysnettet så længe netstikket sidder i stikkontakten.

S

Klass 1 laseraparat
Varning! Om apparaten används på annat sätt än i denna bruksanvisning specificerats, kan användaren utsättas för osynlig laserstrålning, som överskrider gränsen för laserklass 1.

Observera! Stömbrytaren är sekundärt kopplad och bryter inte strömmen från nätet. Den inbyggda nätdelen är därför ansluten till elnätet så länge stickproppen sitter i vägguttaget.

SF

Luokan 1 laserlaite
Varoitus! Laitteen käyttäminen muulla kuin tässä käyttöohjeessa mainitulla tavalla saattaa altistaa käyttäjän turvallisuusluokan 1 ylittävälle näkymättömälle lasersäteilylle. Oikeus muutoksiin varataan. Laite ei saa olla alttiina tippu-ja roiskevedelle.

Huom. Toiminnanvalitsin on kytketty toisiopuolelle, eikä se kytke laitetta irti sähköverkosta. Sisäänrakennettu verkko-osa on kytkettynä sähköverkkoon aina silloin, kun pistoke on pistorasiassa.

The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on apparatus.

Due to the inconsistency of disc formats provided by various disc manufacturers, your DVD system may require a playability enhancement or upgrade. As DVD technology advances, these enhancements will become common and will be easy to complete.

General Information

Environmental Information

All unnecessary packaging has been omitted. The packaging has been made easy to separate into three materials: cardboard (box), polystyrene foam (buffer) and polyethylene (bags, protective foam sheet).

Your DVD player consists of materials which can be recycled and reused if disassembled by a specialised company. Please observe the local regulations regarding the disposal of packaging materials, exhausted batteries and old equipment.

Manufactured under license from Dolby Laboratories. "Dolby", "Pro Logic" and the double-D symbol are trademarks of Dolby Laboratories.

Laser safety

This unit employs a laser. Due to possible eye injury, only a qualified service person should remove the cover or attempt to service this device.

NOTE:
PICTURES SHOWN MAYBE DIFFERENT BETWEEN COUNTRIES.

CAUTION
(WARNING LOCATION: ON THE BACKPLATE OF THE SET)

NEVER MAKE OR CHANGE CONNECTIONS WITH THE POWER SWITCHED ON.

Important Note:
Due to the numerous versions of new CD-Audio copy protection or enhanced CD-Audio protection recently available on certain discs. Should you have difficulty playing any such CD-Audio discs, kindly refer them to your CD-Audio disc retailer.

CE This DVD player is in conformity with the EMC directive and low-voltage directive.

For Customer Use:

Read carefully the information located at the bottom of your DVD VIDEO player and enter below the Serial No. Retain this information for future reference.

Model No. MDV430
Serial No. _____

LASER	
Type	Semiconductor laser GaAlAs
Wave length	650 nm (DVD) 780 nm (VCD/CD)
Output Power	7 mW (DVD) 10 mW (VCD/CD)
Beam divergence	60 degree

Index

English ---------- **6**

Deutsch ---------- **31**

Italiano ---------- **57**

Svenske ---------- **85**

Dansk ---------- **111**

Suomi ---------- **137**

English

Deutsch

Italiano

Svenska

Dansk

Suomi

CAUTION
VISIBLE AND INVISIBLE LASER RADIATION WHEN OPEN.
AVOID EXPOSURE TO BEAM.
ADVARSEL
SYNLIG OG USYNLIG LASERSTRÅLING VED ÅBNING
UNDGÅ UDSÆTTELSE FOR STRÅLING
VARNING
SYNLIG OCH OSYNLIG LASERSTRÅLNING NÄR DENNA DEL ÄR ÖPPNAD BETRAKTA EJ STRÅLEN
VARO!
AVATTAESSA OLET ALTTIINA NÄKYVÄLLE JA NÄKYMÄTTÖMÄLLE LASER SÄTEILYLLE. ÄLÄ KATSO SÄTEESEEN
VORSICHT
GEFAHR VON SICHTBARER UND UNSICHTBARER LASERSTRAHLUNG BEI GEÖFFNETEM GEHÄUSE.
ATTENTION
RAYONNEMENT LASER VISIBLE ET INVISIBLE EN CAS D'OUVERTURE EXPOSITION DANGEREUSE AU FAISCEAU

01-30 MDV430_Eng1 5 28/09/2004, 2:26 PM 3139 246 14551

English

Contents

Introduction
Supplied accessories 7
Care and safety information 7

Connections
Connecting TV 8-9
- Using SCART jack 8
- Using Composite Video jacks (CVBS) 8
- Using an accessory RF modulator 9

Connecting the power cord 9
Optional : Connecting to an Audio System 10
- Stereo system has Dolby Pro Logic or Right / Left Audio In jack 10

Optional: Connecting Digital AV Receiver 10
- Receiver has a PCM, Dolby Digital, or MPEG2 decoder 10

Functional Overview
Front and Rear Panels 11
Remote Control 12

Getting Started
Step 1: Inserting batteries into the Remote Control 13
- Using the Remote Control to operate the Player 13

Step 2: Setting up the TV 13-14
- To deactivate Progressive manually ... 13-14
- Selecting the colour system that corresponds to your TV 14

Step 3: Setting language preference 15
- Setting the OSD Language 15
- Setting the Audio, Subtitle and DVD menu language 15

Disc Operations
Playable Discs 16
Region Codes 16
Playing discs 17
Using Disc Menu 17
Basic playback controls 18-19
- Pausing playback 18
- Selecting track/chapter 18
- Resuming playback from the last stopped point 18
- Zoom 18
- Repeat 18
- Repeat A-B 18
- Slow Motion 19
- Forward / Reverse Searching 19
- Preview 19

Special DVD features 20
- Selecting a Title 20
- Camera Angle 20
- Changing the Audio Language 20
- Subtitles 20

Playing MP3/JPEG Picture CD/DivX 20-21
- General Operation 20
- Playback selection 21
- Repeat 21
- Zoom picture 21
- Playback with multi-angles 21
- Scan Effect 21

DVD Menu Options
Language 22
- OSD Menu 22
- Audio, Subtitle, DVD Menu 22
- Setting the DivX Subtitle 22

Video Setup 23
- TV Display 23
- TV Type 23

Audio Setup 23-24
- Digital Output 23
- LPCM Output 24
- Night Mode - turning on/off 24

Rating 25-26
- Changing the Password 25
- Setting the Rating 25-26
- Restoring to original settings 26
- DivX registration 26

Specifications 27

Troubleshooting 28–29

Glossary 30

01-30 MDV430_Eng1 6 28/09/2004, 2:26 PM 3139 246 14551

English

Supplied accessories

Remote Control
and
two AAA batteries



Care and safety information

- **Power consumption**
  – When the system is switched to Standby mode, it is still consuming power. To disconnect the system from the power supply completely, remove the AC power plug from the wall jack.

- **Avoid high temperatures, moisture, water and dust**
  – Do not expose the player, batteries or discs to humidity, rain, sand or excessive heat (caused by heating equipment or direct sunlight.)

- **Avoid condensation problem**
  – The lens may cloud over when the player is suddenly moved from cold to warm surroundings, making it impossible to play a disc. Leave the player in the warm environment until the moisture evaporates.

- **Do not block the vents**
  – Do not operate the DVD Player in an enclosed cabinet, allow about 2.5 cm (1 inch) of free space all around the player for adequate ventilation.



- **Care of the cabinet**
  – Use a soft cloth slightly moistened with a mild detergent solution. Do not use a solution containing alcohol, spirits, ammonia or abrasives.

- **Finding a suitable location**
  – Place the player on a flat, hard, and stable surface.

- **Disc handling**
  – To clean a CD, wipe it in a straight line from the center towards the edge using a soft, lint-free cloth. A cleaning agent may damage the disc!
  – Write only on the printed side of a CDR(W) and only with a soft felt-tipped pen.
  – Handle the disc by its edge, do not touch the surface.



01-30 MDV430_Eng1 7 28/09/2004, 2:26 PM 3139 246 14551

Connections

Connecting TV





IMPORTANT!
– You only need to make one video connection from the following options, depending on the capabilities of your TV system.
– Connect the DVD system directly to the TV.
– SCART connection will let you use the features of both the Audio and Video in the DVD Player.

Using SCART jack

- Use the SCART cable (black) to connect the DVD Player's SCART jack (**TV OUT**) to the corresponding Scart input jacks on the TV *(cable not supplied)*.

Helpful Hint:
– Ensure that the "TV" indication on SCART cable is connected to the TV set and "DVD" indication on SCART cable is connected to the DVD Player.

Using Composite Video jacks (CVBS)

1. Use the composite video cable (yellow) to connect the DVD Player's CVBS (VIDEO) jack to the video input jack (or labeled as A/V In, Video In, Composite or Baseband) on the TV *(cable not supplied)*.
2. To hear the sound of this DVD Player through your TV, use the audio cables (white/red) to connect AUDIO OUT (L/R) jacks of the DVD Player to the corresponding AUDIO IN jacks on the TV *(cable not supplied)*.

01-30 MDV430_Eng1 8 28/09/2004, 2:26 PM 3139 246 14551

English



IMPORTANT!
– If your TV only has a single Antenna In jack (or labeled as 75 ohm or RF In,) you will need an RF modulator in order to view the DVD playback on the TV. See your electronics retailer for details on RF modulator availability and operations.

Using an accessory RF modulator

1. Use the composite video cable (yellow) to connect the DVD Player's **CVBS** jack to the video input jack on the RF modulator.
2. Use the RF coaxial cable (not supplied) to connect the RF modulator to your TV's RF jack.

Connecting the power cord



After everything is connected properly, plug in the AC power cord to the power outlet.
Never make or change any connections with the power switched on.

When no disc is loaded, **press STANDBY ON on the DVD Player front panel,**
"NO DISC" may appear on the display panel.



01-30 MDV430_Eng1 9 28/09/2004, 2:26 PM 3139 246 14551

Connections

Optional: Connecting to an Audio System



Stereo system has Dolby Pro Logic or Right / Left Audio In jack

1. Select one of the video connections (CVBS VIDEO IN, S-VIDEO IN, SCART or COMPONENT VIDEO IN) depending on the options available on your TV.
2. Use the audio cables (white/red) to connect **AUDIO OUT (L/R)** jacks of the DVD Player to the corresponding AUDIO IN jacks on the stereo system *(cable not supplied)*.

Optional: Connecting Digital AV Receiver



Receiver has a PCM, Dolby Digital, or MPEG2 decoder

1. Select one of the video connections (CVBS VIDEO IN, S-VIDEO IN, SCART or COMPONENT VIDEO IN) depending on the options available on your TV.
2. Connect the COAXIAL jack of the DVD Player to the corresponding Digital Audio In jack on your Receiver *(cable not supplied)*.
3. Set the DVD Player's Digital Output to PCM or ALL depending on the capabilities of your Receiver *(see page 24 "Digital Output")*.

Helpful Hint:
– If the audio format of the Digital Output does not match the capabilities of your receiver, the receiver will produce a strong, distorted sound or no sound at all.

01-30 MDV430_Eng1 10 28/09/2004, 2:26 PM 3139 246 14551

English

Front and Rear Panels

OPEN/CLOSE ▲
– Open/Close the disc tray

STANDBY-ON ⏻
– To switch the DVD Player to Standby mode or ON

▶II PLAY/PAUSE
– To start or interrupt playback

Disc tray

■ STOP
– To stop playback

Display
– Shows the current status of the DVD Player

IR Sensor
– Point the remote control towards this sensor



Mains (AC Power Cord)
– Connect to a standard AC outlet

Scart
– Connect to Scart input of a TV

COAXIAL (Digital audio out)
– Connect to coaxial AUDIO input of a digital audio equipment

Audio Out (Left/Right)
– Connect to AUDIO inputs of an amplifier, receiver or stereo system

CVBS (VIDEO Out)
– Connect to CVBS Video input of a TV



Caution: Do not touch the inner pins of the jacks on the rear panel. Electrostatic discharge may cause permanent damage to the unit.

Functional Overview

Remote Control



POWER ⏻
– To switch the DVD player to standby mode or ON

0-9 numerical key pad
– Selects numbered items in a menu

RETURN/TITLE
– To go back to previous menu/show title menu

⏮
– To search or select previous chapter or track

PLAY (►)
– To start playback

STOP (■)
– To stop playback

OK
– Acknowledge menu selection

DISC MENU
– Enters or exits the disc contents menu
– Switches on or off the playback control mode (for VCD version 2.0 only)

REPEAT
– Selects various repeat modes

REPEAT (A-B)
– Repeats playback a specific section on a disc

AUDIO
– To access audio language system menu

PREVIEW
– To search chapter/track during playback

MUTE
– Disables or enables sound output

DISPLAY
– Displays information on TV screen during playback

⏭
– To search or select next chapter or track

PAUSE (II)
– To pause playback temporarily / frame-by-frame playback

◄ ► ▲ ▼
– Selects an item in the menu/ fast forward/backward, slow forward/ backward

SYSTEM MENU
– Access or exit DVD Player's system menu

SUBTITLE
– To access subtitle language system menu

ANGLE
– Selects a DVD camera angle

ZOOM
– Enlarge a picture on the TV screen

Helpful Hint:
Press "STOP" for about 2 seconds to OPEN or CLOSE disc tray.

01-30 MDV430_Eng1 12 28/09/2004, 2:26 PM 3139 246 14551

English

Step 1: Inserting batteries into the Remote Control



1. Open the battery compartment.
2. Insert two batteries type R03 or AAA, following the indications (+ −) inside the compartment.
3. Close the cover.

Using the Remote Control to operate the Player

1. Aim the Remote Control directly at the remote sensor (iR) on the front panel.
2. Do not put any objects between the Remote Control and the DVD Player while operating the DVD Player.



CAUTION!
– Remove batteries if they are exhausted or if the Remote Control is not being used for a long time.
– Do not use old and new or different types of batteries in combination.
– Batteries contain chemical substances, so they should be disposed properly.

Step 2: Setting up the TV

IMPORTANT!
Make sure you have completed all the necessary connections. (See page 8-9 "Connecting TV").

1. Turn on the TV and set to the correct video-in channel. You should see the DVD background screen on the TV.
2. Usually these channels are between the lowest and highest channels and may be called FRONT, A/V IN, or VIDEO. See your TV manual for more details.
   ➜ Or, you may go to channel 1 on your TV, then press the Channel down button repeatedly until you see the Video In channel.
   ➜ Or, the TV Remote Control may have a button or switch that chooses different video modes.
   ➜ Or, set the TV to channel 3 or 4 if you are using an RF modulator.
3. If you are using external equipment, (eg. audio system or receiver), turn it on and select the appropriate input source for the DVD Player output. Refer to the equipment owner's manual for detail.

01-30 MDV430_Eng1 13 28/09/2004, 2:26 PM 3139 246 14551

Getting Started

Selecting the colour system that corresponds to your TV

This DVD Player is compatible with both NTSC and PAL. In order for a DVD disc to play on this Player, the colour system of the Disc, the TV and the DVD Player should match.



1. Press **SYSTEM MENU**.
2. Press ▶ repeatedly to select {VIDEO}, then press **OK**.
3. Press ▲▼ to highlight {TV TYPE}.
4. Enter its submenu by pressing **OK**.
5. Press ▲▼ to highlight one of the options below:

   PAL – Select this if the connected TV is PAL system. It will change the video signal of a NTSC disc and output in PAL format.

   NTSC – Select this if the connected TV is NTSC system. It will change the video signal of a PAL disc (VCD only) and output in NTSC format.

   Multi – Select this if the connected TV is compatible with both NTSC and PAL (multi-system). The output format will be in accordance with the video signal of the disc.
6. Select an item and press **OK**.
   ➜ Follow the instructions show on the TV to confirm the selection (if any).
   ➜ If a blank/distorted TV screen appears, wait for 15 seconds for auto recovery.

Setting the TV Display

Set the aspect ratio of the DVD Player according to the TV you have connected. The format you select must be available on the disc. If it is not, the setting for TV display will not affect the picture during playback.



1. Press **SYSTEM MENU**.
2. Press ▶ repeatedly to select {VIDEO}, then press **OK**.
3. Press ▲▼ to highlight {TV DISPLAY}.
4. Enter its submenu by pressing **OK**.
5. Press ▲▼ to highlight one of the options below:

4:3 PANSCAN – Select this if you have a normal TV and want both sides of the picture to be trimmed or formatted to fit your TV screen.

4:3 LETTERBOX – Select this if you have a normal TV. In this case, a wide picture with black bands on the upper and lower portions of the TV screen will be displayed.

16:9 – Select this if you have a wide-screen TV.

6. Select an item and press **OK**.

TIPS: To return to the previous menu, press **OK**.
To remove the menu, press **SYSTEM MENU**.

01-30 MDV430_Eng1 14 28/09/2004, 2:26 PM 3139 246 14551

Step 3: Setting language preference

You can select your preferred language settings. This DVD Player will automatically switch to the language for you whenever you load a disc.

Setting the OSD Language

The On-screen language for the system menu will remain as you set it, regardless of various disc languages.



1. Press **SYSTEM MENU**.
2. Press ▶ to select {LANGUAGE}, then press **OK**.
3. Press ▲▼ to highlight {OSD MENU}.
4. Enter its submenu by pressing **OK**.
5. Press ▲▼ to select a language and press **OK**.

Setting the Audio, Subtitle and DVD menu language

You can choose your own preferred language or soundtrack from audio, subtitles and DVD menu languages. If the language selected is not available on the disc, the disc's default language will be used instead.



1. Press **SYSTEM MENU**.
2. Press ▶ to select {LANGUAGE}, then press **OK**.
3. Press ▲▼ to highlight one of the options below at a time, then press **OK**.
   – 'Subtitle' (disc's subtitles)
   – 'Audio' (disc's soundtrack)
   – 'DVD Menu' (disc's menu)
4. Press ▲▼ to select a language and press **OK**.
5. Repeat steps 3~4 for other language settings.

TIPS: To return to the previous menu, press **OK**.
To remove the menu, press **SYSTEM MENU**.

Disc Operations

IMPORTANT!
– Depending on the DVD or VIDEO CD, some operations may be different or restricted.
– Do not push on the disc tray or put any objects other than disc on the disc tray. Doing so may cause the disc player malfunction.

Playable Discs

Your DVD Player will play:
– Digital Versitile Discs (DVDs)
– Video CDs (VCDs)
– Digital Video Discs + Recordable [Rewritable] (DVD+R[W])
– Compact Discs (CDs)
– MP3 discs, picture (JPEG) files on CD-R(W).
  – JPEG/ISO 9660 format
  – Maximum 30 characters display.
  – Supported sampling frequencies : 32 kHz, 44.1 kHz, 48 kHz (MPEG-1) 16 kHz, 22.05 kHz, 24 kHz (MPEG-2)
  – Supported Bit-rates : 32~256 kbps (MPEG-1), 8~160 kbps (MPEG-2) variable bitrates
– DivX disc on CD-R[W]/DVD+R[W]:
  – DivX 3.11, 4.x and 5.x
  – Q-pel accurate motion compensation
  – Global Motion Compensation (GMC) playback

Helpful Hints:
– It may not be possible to play CD-R/RW or DVD-R/RW in all cases due to the type of disc or condition of the recording.
– If you are having trouble playing a certain disc, remove the disc and try a different one. Improper formatted disc will not play on this DVD Player.

Region Codes

This DVD Player is designed to support the Region Management System. Check the regional code number on the disc package. If the number does not match the Player's region number (see table below), the Player may be unable to playback the disc.

Region	Region number of the unit	Discs that can be played (Example)
U.S.A. and Canada regions	1	ALL, 1
U.K and Europe regions	2	ALL, 2
General regions	3	ALL, 3
Australia region	4	ALL, 4

TIPS: The operating features described here might not be possible for certain discs. Always refer to the instructions supplied with the discs.

01-30 MDV430_Eng1 16 28/09/2004, 2:26 PM 3139 246 14551

IMPORTANT!
If the inhibit icon (ø) appears on the TV screen when a button is pressed, it means the function is not available on the current disc or at the current time.

Playing discs

1. Connect the power cords of the DVD Player and TV (and any optional stereo or AV receiver) to a power outlet.
2. Turn on the TV power and set to the correct Video In channel. (See page 13 "Setting up the TV").
3. Press **STANDBY-ON** on the DVD Player front panel.
   ➜ You should see the DVD background screen on the TV.
4. Press **OPEN/CLOSE ≜** button to open the disc tray and load in a disc, then press the same button again to close the disc tray.
   ➜ Make sure the label side is facing up. For double-sided discs, load the side you want to play facing up.
5. Playback will start automatically. If not press **PLAY ►**.
   ➜ If a disc menu appears on the TV, see "Using the Disc Menu".
   ➜ If the disc is locked by parental control, you must enter your four-digit password. (See page 25).
6. At any time, simply press **STOP** to stop playback.

Using the Disc Menu

Depending on the disc, a menu may appear on the TV screen once you load the disc.

To select a playback feature or item

- Use the ◄ ► ▲ ▼ or **numeric keypad (0-9)** on the Remote Control, then press **PLAY ►** to start playback.

To access or exit from the menu

- Press **DISC MENU** on the Remote Control.

For VCD with Playback Control (PBC) feature (version 2.0 only)

PBC playback allows you to play Video CDs interactively, following the menu on the display.

- In stop mode, use the **numeric keypad (0-9)** to select a track and PBC will turn off.
  ➜ Playback will start automatically
- During playback, press **DISC MENU**;
  ➜ If PBC was ON, it will switch to OFF and continue playback.
  ➜ If PBC was OFF, it will switch to ON and return to menu screen.
- During playback, pressing **RETURN/ TITLE** will return to the menu screen (if PBC is on).

Disc Operations

Basic playback controls

Unless otherwise stated, all operations described are based on the use of Remote Control.

Pausing playback (DVD/VCD/CD/MP3)

1. During playback, press **PAUSE II**.
   ➜ Playback will pause and sound will be muted.
2. Press **PAUSE II** again to select the next picture frame.
3. To return to normal playback, press **PLAY ►**.

Selecting track/chapter (DVD/VCD/CD)

1. Press ►►| briefly during playback to go to the next chapter/track
2. Press |◄◄ to go to the previous track (VCD/CD) or return to the beginning of the current chapter (DVD).
- Press |◄◄ twice briefly to step back to the previous chapter (DVD).
3. To go directly to any chapter/track, enter the chapter/track number using the numerical keys (0-9).

Resuming playback from the last stopped point (DVD/VCD/CD)

Resume playback of the last five discs, even if the disc was removed from the Player.

1. Load one of the last five discs.
   ➜ "LOAD" appears.
2. Press **PLAY ►** and the disc will play from the last point.
3. Press **STOP ■** to cancel the resume mode.

Helpful Hint:
– *To memorise the last stop point, press OPEN/CLOSE or STANDBY-ON button during playback.*

Zoom (DVD/VCD/JPEG)

Zooming allows you to enlarge or reduce the video image during playback.

1. Press **ZOOM** repeatedly to increase and decrease the playback video image.
2. Press ◄►▲▼ to pan across the TV screen.

Repeat (DVD/VCD)

- Press **REPEAT** continuously to choose a Repeat mode during playback.

REPEAT CHAPTER (DVD)
– to repeat playback of the current chapter.

REPEAT TITLE (DVD)
– to repeat playback of the current title.

REPEAT SINGLE (VCD)
– to repeat playback of the current track.

REPEAT ALL (VCD)
– to repeat playback of all the disc.

REPEAT OFF (DVD/VCD)
– to cancel the repeat mode.

Helpful Hint:
– *REPEAT function is not available for VCD 2.0 when PCB is on.*

Repeat A-B (DVD/VCD/CD)

1. Press **REPEAT A-B** at your chosen starting point.
2. Press **REPEAT A-B** again at your chosen end point.
   ➜ The section A and B can be set only within the same chapter/track.
   ➜ The section will now repeat continuously.
3. To exit the sequence, press **REPEAT A-B**.

TIPS: The operating features described here might not be possible for certain discs. Always refer to the instructions supplied with the discs.

01-30 MDV430_Eng1 18 28/09/2004, 2:26 PM 3139 246 14551

Slow Motion (DVD/VCD)

1. Press ▲▼ during playback to select the required speed: 1/2, 1/4, 1/8 or 1/16 (backward or forward).
   ➜ Sound will be muted.
2. To return to normal speed, press **PLAY ►**.

Helpful Hint:
– *Slow backward is not possible on VCDs.*

Forward / Reverse Searching (DVD/VCD/CD)

1. Press ◄► during playback to select the required speed: 2X, 4X, 8X or 16X (backward or forward).
   ➜ Sound will be muted (DVD/VCD) or intermittent (CD).
2. To return to normal speed, press **PLAY ►**.

Preview (DVD/VCD)

The Time Search function allows you to start playing at any chosen time on the disc.

1. Press **PREVIEW**.
2. Use ◄► keys to select an option.
3. Enter hours, minutes and seconds from left to right in the time edit box using remote control numerical key pad. (e.g. 0:34:27)
4. Press the **OK** key to confirm.
   ➜ Playback starts from the selected time on the disc.

TIPS: The operating features described here might not be possible for certain discs. Always refer to the instructions supplied with the discs.

01-30 MDV430_Eng1 19 28/09/2004, 2:26 PM 3139 246 14551

Disc Operations

Special DVD features

Selecting a title

Some DVDs may contain several titles. If the disc has a title menu recorded on it, you can start playback from the selected movie title.

1. Press **DISC MENU**.
   ➜ The disc title menu appears on the TV screen.
2. Use ▲▼◄► keys or **numeric keypad (0-9)** to select a title.
3. Press **OK** key to confirm.

Camera Angle

If the disc contains sequences recorded from different angle, this allows you to view picture from different angle.

- Press **ANGLE** repeatedly to select different desired angle.
  ➜ Playback changes to the selected angle.

Changing the Audio Language

For DVD

- Press **AUDIO** repeatedly to select different audio languages.

Subtitles

- Press **SUBTITLE** repeatedly to select different subtitle languages.

Playing MP3/JPEG Picture CD/ DivX

This player can playback MP3, DivX, JPEG, or Picture CD files on a personally recorded CD-R/RW disc or commercial CD.

IMPORTANT!
You have to turn on your TV and set to the correct Video In channel. (See page 13 "Setting up the TV").

General Operation

1. Load a disc.
   ➜ Playback will start automatically. If not press **PLAY ►**.
- Press **STOP** to display disc menu on the TV screen.
2. Use ▲ ▼ to select the folder and press **OK** to open the folder.







3. Press ▲ ▼ or use the numeric keypad (0-9) to highlight an option.
4. Press **OK** to confirm.

TIPS: The operating features described here might not be possible for certain discs. Always refer to the instructions supplied with the discs.

01-30 MDV430_Eng1 20 28/09/2004, 2:26 PM 3139 246 14551

Playback selection

During playback, you can;

- Press |◄◄ / ►►| to select another file in the current folder.
- Use ◄►▲▼ on the remote to rotate/flip the picture files.
- Press ❚❚ / ► repeatedly to pause/resume playback.

Repeat

- Press **REPEAT** continuously to access different 'Play Mode'.

REPEAT SINGLE
– to repeat playback of the current file.

REPEAT ALL
– to repeat playback of all files in the disc.

REPEAT OFF
– to cancel the repeat mode.

Zoom picture (JPEG / DivX)

- During playback, press **ZOOM** repeatedly to display the picture with different scales.
- Use ◄►▲▼ to view the zoomed picture.

Playback with multi-angles (JPEG)

- During playback, press ▲▼◄► to rotate the picture on the TV screen.
  ▲: flip the picture vertically
  ▼: flip the picture horizontally
  ◄: rotate the picture anti-clockwise
  ►: rotate the picture clockwise

Scan Effect (JPEG)

- Press **ANGLE** repeatedly to choose different scan effect.
  ➜ Various scan effect appears on the top left hand corner on the TV screen.

TIPS: The operating features described here might not be possible for certain discs. Always refer to the instructions supplied with the discs.

English

DVD Setup Menu Options

This DVD Player setup is carried out via the TV, enabling you to customise the DVD Player to suit your particular requirements.

Language

1. Press **SYSTEM MENU**.
2. Press ▶ to select {LANGUAGE}.
3. Press **OK** to confirm.



OSD Menu

This menu contains various language options for display language on the screen. For details, see page 15.

Audio, Subtitle, DVD Menu

These menus contain various language options for audio, subtitle and DVD menu which may be recorded on the DVD disc. For details, see page 15.

Setting the DivX Subtitle

- **When selecting an embedded subtitle during playback,**
  Load a DivX disc and press **SUBTITLE** repeatedly to select available subtitle.
  OR
- **When selecting an external DivX text subtitle during playback,**
  If available on the recorded disc, you can select the external DivX subtitle in text format.

1. In 'LANGUAGE', press **OK** to enter the submenu.
2. Press ▲ ▼ to highlight {DIVX SUBTITLE}.
3. Enter its submenu by pressing **OK**.
4. Press ▲ ▼ to highlight one of the options below:

   Standard
   A standard list of English subtitle fonts provided by this DVD Player.

   Cent.Eur
   Select this to display a cyrillic subtitle fonts.
5. Press ▲ ▼ to select a setting, then press **OK** to confirm your selection.

- You can also press **SUBTITLE** repeatedly to select available subtitle.

Helpful Hints:
– Subtitle files with the following filename extensions (.srt, .smi, .sub, .ssa, .ass) are supported but do not appear on the file navigation menu.
– The subtitle filename have to be the same as the filename of the movie.

TIPS: To return to the previous menu, press **OK**.
To remove the menu, press **SYSTEM MENU**.

01-30 MDV430_Eng1 22 28/09/2004, 2:26 PM 3139 246 14551

DVD Setup Menu Options

Video Setup

1. Press **SYSTEM MENU**.
2. Press ▶ repeatedly to select {VIDEO SETUP}.
3. Press **OK** to confirm.



TV Display

This menu contains the options for setting the aspect ratio of the DVD Player according to the connected TV. For details, see page 14.

TV Type

This menu contains the options for selecting the color system that matches the connected TV. For details, see page 14.

Audio Setup

1. Press **SYSTEM MENU**.
2. Press ▶ repeatedly to select {AUDIO SETUP}.
3. Press **OK** to confirm.



Digital Output

Set the Digital output according to your optional audio equipment connection.



1. In 'AUDIO SETUP', press **OK** to enter the submenu.
2. Press ▲▼ to highlight {DIGITAL OUTPUT}, then press **OK**.
3. Press ▲▼ to highlight one of the options below:

OFF
Turn off the digital output.

ALL
If you have connected your DIGITAL AUDIO OUT to a multi-channel decoder/ receiver.

PCM
Only if your receiver is not capable of decoding multi-channel audio.

4. Select an item and press **OK**.

Helpful Hint:
– *If DIGITAL OUTPUT is set to 'All', all audio settings except MUTE are invalid.*

TIPS: To return to the previous menu, press **OK**.
To remove the menu, press **SYSTEM MENU**.

01-30 MDV430_Eng1 23 28/09/2004, 2:26 PM 3139 246 14551

DVD Setup Menu Options

LPCM Output

If you connect the DVD Player to a PCM compatible receiver via the digital terminals, such as coaxial or optical etc, you may need to adjust 'LPCM Output'. Discs are recorded at a certain sampling rate. The higher the sampling rate, the better the sound quality.



1. In 'AUDIO SETUP', press **OK** to enter the submenu.
2. Press ▲ ▼ to highlight {LPCM Output}, then press **OK**.
3. Press ▲ ▼ to highlight one of the options below:

   48kHz
   Playback a disc recorded at the sampling rate of 48kHz.

   96kHz
   Playback a disc recorded at the sampling rate of 96kHz that can only be achieved in Stereo-Classic mode.
4. Select an item and press **OK**.

Helpful Hint:
– *LPCM Output can be selected only when PCM is activated.*

Night Mode - turning on/off

In this mode, the high volume outputs are softened and low volume outputs are brought upward to an audible level. It is useful for watching your favourite action movie without disturbing others at night.



1. In 'AUDIO SETUP', press **OK** to enter the submenu.
2. Press ▲ ▼ to highlight {Night Mode}, then press **OK**.
3. Press ▲ ▼ to highlight one of the options below:

   ON
   Select this to level out the volume. This feature is only available for movies with Dolby Digital mode.

   OFF
   Select this when you want to enjoy the surround sound with its full dynamic range.
4. Select an item and press **OK**.

TIPS: To return to the previous menu, press **OK**.
To remove the menu, press **SYSTEM MENU**.

01-30 MDV430_Eng1 24 28/09/2004, 2:26 PM 3139 246 14551

Rating

1. Press **SYSTEM MENU**.
2. Press ▶ repeatedly to select {RATING}.
3. Press **OK** to confirm.



Changing the Password

The same password is used for both Parental Control. Enter your 4 digit password when prompted on the screen. The default password is 0000.

1. In 'RATING', press **OK** to enter the submenu.
2. Use the **numeric keypad (0-9)** to enter your old four-digit password.
   ➜ When doing this for the first time, key in '0000'.
   ➜ If you forget your old four-digit password, key in '0000'.
3. Enter the new four-digit password.
4. Enter the new four-digit password a second time to confirm.
   ➜ The new four-digit password will now take effect.



5. Press **OK** to confirm.

Setting the Rating

Some DVDs may have a parental level assigned to the complete disc or to certain scenes on the disc. This feature lets you set a playback limitation level. The rating levels are from 1 to 8 and are country dependent. You can prohibit the playing of certain discs that are not suitable for your children or have certain discs played with alternative scenes.

1. In 'RATING', press **OK** to enter the submenu.
2. Press ▲ ▼ to highlight {RATING}, then press **OK** to sel.ect a rating level for the disc inserted.
   ➜ To disable rating controls and have all Discs play, select {1 KID SAFE}.
3. Use the **numeric keypad (0-9)** to enter the four-digit password (see page 25 "Changing the password").
   ➜ DVDs that are rated above the level you selected will not play unless you enter your four-digit password.

Helpful Hints:
– VCD, CD have no level indication, so parental control function has no effect on these type of discs. This applies to most illegal DVD discs.
– Some DVDs are not encoded with a rating though the movie rating may be printed on the Disc cover. The rating level feature does not work for such Discs.

TIPS: To return to the previous menu, press **OK**.
To remove the menu, press **SYSTEM MENU**.

DVD Setup Menu Options

Rating explanations

1 KID SAFE
– Kids material; recommended especially for children and viewers of all ages.

2 G
– General Audience; recommended as acceptable for viewers of all ages.

3 PG
– Parental Guidance suggested.

4 PG13
– Material is unsuitable for children under age 13.

5-6 PG-R
– Parental Guidance - Restricted; recommended that parents restrict children under 17 from viewing or allow to view only when supervised by a parent or adult guardian.

7 NC-17
– No children under age 17; not recommended viewing for children under age 17.

8 ADULT
– Mature material; should be viewed only by adults due to graphic sexual material, violence or language.

Restoring to original settings

Setting the 'Default' function will reset all options and your personal settings to the factory defaults and all your personal settings will be erased.

1. In 'RATING', press **OK** to enter the submenu.
2. Press ▲ ▼ to highlight {DEFAULT}, then select {RESET}.
3. Press **OK** to confirm.
   ➜ All settings will now reset to factory defaults.

DivX registration

This DVD Player provides you the DivX® VOD (Video On Demand) registration code that allows you to rent and purchase videos using the DivX® VOD service.
For more information, visit www.divx.com/vod.

1. In 'RATING', press **OK** to enter the submenu.
2. Press ▲ ▼ to highlight {DivX REGISTRATION}, then select {DISPLAY}.
3. Press **OK** on the remote control.
   ➜ The registration code will appear.



4. Use the registration code to purchase or rent the videos from DivX® VOD service at www.divx.com/vod.
   Follow the instrucitons and download the video onto a CD-R for playback on this DVD player.

Helpful Hint:
– *All the downloaded videos from DivX® VOD can only be played back on this DVD player.*

TIPS: To return to the previous menu, press **OK**.
To remove the menu, press **SYSTEM MENU**.

01-30 MDV430_Eng1 26 28/09/2004, 2:26 PM 3139 246 14551

Specifications

English

TV STANDARD (PAL/50Hz) (NTSC/60Hz)

Number of lines	625	525
Playback	Multistandard	(PAL/NTSC)

VIDEO PERFORMANCE

DA Converter	12 bit, 54mHz
Video Output	1Vpp — 75 ohm
RGB (SCART) output	0.7Vpp — 75 ohm

AUDIO FORMAT

Digital	MPEG	compressed Digital
	PCM	16, 20, 24 bits fs, 44.1, 48, 96 kHz
MP3(ISO 9660)		96, 112, 128, 256 kbps & variable bit rate fs, 32, 44.1, 48 kHz

Analog Sound Stereo
Dolby Surround compatible downmix from Dolby Digital multi-channel sound

AUDIO PERFORMANCE

DA Converter	24 bit, 192 kHz	
DVD	fs 96 kHz	4Hz- 44kHz
	fs 48 kHz	4Hz- 22kHz
CD/VCD	fs 44.1kHz	4Hz- 20kHz
Signal-Noise (1kHz)		90 dB
Dynamic range(1kHz)		90 dB
Crosstalk (1kHz)		100 dB
Distortion/noise (1kHz)		80 dB
MPEG MP3	MPEG Audio L3	

CONNECTIONS

Scart Output	Euroconnector
Video Output	Cinch (yellow)
Audio Output(L+R)	Cinch (white/red)
Digital Output	1 coaxial IEC60958 for CDDA / LPCM IEC61937 for MPEG 1/2, Dolby Digital

CABINET

Dimensions (w x h x d)	360 x 50 x 285 mm
Weight	Approximately 2.2 kg

POWER CONSUMPTION

Power Supply Rating	220 – 240V; 50-60 Hz
Power consumption	12 W
Power consumption in Standby mode	< 2W

Specifications subject to change without prior notice

01-30 MDV430_Eng1 27 28/09/2004, 2:26 PM 3139 246 14551

Troubleshooting

WARNING
Under no circumstances should you try to repair the system yourself, as this will invalidate the warranty. Do not open the system as there is a risk of electric shock.

If a fault occurs, first check the points listed below before taking the system for repair.

Problem	Solution
No power	– Check if the AC power cord is properly connected. – Press the STANDBY ON on the front of the DVD system to turn on the power.
No picture	– Refer to your TV's manual for correct Video In channel selection. Change the TV channel until you see the DVD screen. – Check if the TV is switched on.
Distorted picture	– Sometimes a small amount of picture distortion may appear depending on the disc being played back. This is not a malfunction.
Completely distorted picture or black/white picture with DVD	– Connect DVD Player directly to the TV. – Make sure the disc is compatible with the DVD/ Player. – Ensure that the DVD Player's TV Type is set to match that of the Disc and your TV.
No sound or distorted sound	– Adjust the volume. – Check that the speakers are connected correctly.
No audio at digital output	– Check the digital connections. – Check if your receiver can decode MPEG-2 or DTS and if not, please make sure the digital output is set to PCM. – Check if the audio format of the selected audio language matches your receiver capabilities.
No sound and picture	– Check that the RGB/SCART cable is connected to the correct device (See Connecting TV).
Disc can't be played	– The DVD+R/CD-R must be finalised. – Ensure the disc label is facing up. – Check if the disc is defective by trying another disc. – If you have recorded a Picture CD or MP3 CD yourself, ensure that your disc contains at least 10 pictures or 5 MP3 tracks. – Region code incorrect.
Picture freezes momentarily during playback	– Check the disc for fingerprints/scratches and clean with a soft cloth wiping from centre to edge.
No return to start-up screen when disc is removed	– Reset the unit by switching the player off, then on again.

01-30 MDV430_Eng1 28 28/09/2004, 2:26 PM 3139 246 14551

Troubleshooting

Problem	Solution
The player does not respond to the Remote Control	– Aim the Remote Control directly at the sensor on the front of the player. – Reduce the distance to the player. – Replace the batteries in the Remote Control. – Re-insert the batteries with their polarities (+/– signs) as indicated.
Buttons do not work	– To completely reset the player, unplug the AC cord from the AC outlet for 5-10 seconds.
Player does not respond to some operating commands during playback.	– Operations may not be permitted by the disc. Refer to the instructions of the disc jacket.
DVD Player cannot read CDs/DVDs	– Use a commonly available cleaning CD/DVD to clean the lens before sending the DVD Player for repair.
Menu items cannot be selected	– Press STOP twice before selecting System Menu. – Depending on the disc availability, some menu items cannot be selected.
Unable to play DivX movies	– Check that the DivX file is encoded with DivX 3.11, 4.x and 5.x encoder.
No sound during DivX movies playback	– The audio codec may not be supported by the DVD player.

01-30 MDV430_Eng1 29 28/09/2004, 2:26 PM 3139 246 14551

Glossary

Analog: Sound that has not been turned into numbers. Analog sound varies, while digital sound has specific numerical values. These jacks send audio through two channels, the left and right.

Aspect ratio: The ratio of vertical and horizontal sizes of a displayed image. The horizontal vs. vertical ratio of conventional TVs. is 4:3, and that of wide-screens is 16:9.

AUDIO OUT Jacks: Jacks on the back of the DVD System that send audio to another system (TV, Stereo, etc.).

Bit Rate: The amount of data used to hold a given length of music; measured in kilobits per seconds, or kbps. Or, the speed at which you record. Generally, the higher the bit rate, or the higher the recording speed, the better the sound quality. However, higher bit rates use more space on a Disc.

Chapter: Sections of a picture or a music piece on a DVD that are smaller than titles. A title is composed of several chapters. Each chapter is assigned a chapter number enabling you to locate the chapter you want.

Component Video Out Jacks: Jacks on the back of the DVD System that send high-quality video to a TV that has Component Video In jacks (R/G/B, Y/Pb/Pr, etc.).

Disc menu: A screen display prepared for allowing selection of images, sounds, subtitles, multi-angles, etc recorded on a DVD.

Digital: Sound that has been converted into numerical values. Digital sound is available when you use the DIGITAL AUDIO OUT COAXIAL or OPTICAL jacks. These jacks send audio through multiple channels, instead of just two channels as analog does.

DivX 3.11/4x/5x: The DivX codec is a patent-pending, MPEG-4 based video compression technology, developed by DivXNetworks, Inc., that can shrink digital video to sizes small enough to be transported over the internet, while maintaining high visual quality.

Dolby Digital: A surround sound system developed by Dolby Laboratories containing up to six channels of digital audio (front left and right, surround left and right, center and subwoofer).

JPEG: A very common digital still picture format. A still-picture data compression system proposed by the Joint Photographic Expert Group, which features small decrease in image quality in spite of its high compression ratio.

MP3: A file format with a sound data compression system. "MP3" is the abbreviation of Motion Picture Experts Group 1 (or MPEG-1) Audio Layer 3. By using MP3 format. one CD-R or CD-RW can contain about 10 times as much data volume as a regular CD can.

Parental Control: A function of the DVD to limit playback of the disc by the age of the users according to the limitation level in each country. The limitation varies from disc to disc; when it is activated, playback will be prohibited if the software's level is higher than the user-set level.

PCM (Pulse Code Modulation): A system for converting analog sound signal to digital signal for later processing, with no data compression used in conversion.

Playback control (PBC): Refers to the signal recorded on video CDs or SVCDs for controlling reproduction. By using menu screens recorded on a Video CD or SVCD that supports PBC, you can enjoy interactive-type software as well as software having a search function.

Region code: A system for allowing discs to be played back only in the region designated beforehand. This unit will only play discs that have compatible region codes. You can find the region code of your unit by looking on the product label. Some discs are compatible with more than one region (or ALL regions).

S-Video: Produces a clear picture by sending separate signals for the luminance and the color. You can use S-Video only if your TV has S- video In jack.

Title: The longest section of a picture or music feature on DVD, music, etc., in video software, or the entire album in audio software. Each title is assigned a title number enabling you to locate the title you want.

VIDEO OUT jack: Jack on the back of the DVD System that sends video to a TV.

01-30 MDV430_Eng1 30 28/09/2004, 2:27 PM 3139 246 14551